Axle Front / Rear

, but I remit, item.			
	Standard (ft-lb)	Metric (Nm)	
Cover Bolt	16	22	
Drain or Fill plugs	13-18	18-24	
Halfshaft to flange'	57	77	
Mounting bracket to Housing Bolts	125-150	169-203	
Output Flange LockNu	166-196	224-265	
U-Joint to Pinion Yoke			
1/4" Fine Thread	13-18	18-24	
5/16" Fine Threac	27	37	

*Use special 2 piece locking washers (nord-loc's amg part number 06008029)

Brake Caliper Front / Rear

	Standard (ft-lb)	Metric (Nm)
Bleed Screw	6-15	8-20
Cable Braket Screws	20-25	27-34
Caliper Guide Pins	30	41
Caliper Yoke To Adapte	40	54
Lever Retaining Screv	15-25	20-34

Geared Hub

	Standard (ft-lb)	Metric (Nm)
Access Cover	15	20
Access Plug, Half-shaft Bolt	8-13	11-18
Drain / Fill plug	8-13	11-18
Halfshaft to Drive Gear Bol	37	50
Input Seal Plate	30	40
Steering Cove	65	88

Transmission and Transfer Case

	Standard (ft-lb)	Metric (Nm)
Torque Converter to Flywhee	32	44
Transmission Case to Engine	32	44
Transmission Drain Plug	25	34
Transmission Pan	12	16
T-case Drain / Fill plugs	30-40	41-54
T-case Output Yoke Locknu	110	149

Steering System

Steering System			
	Standard (ft-lb)	Metric (Nm)	
Ball joint to Control Arm			
3/8 Fine Threac	28	38	
3/8 Coarse Threac	37	50	
7/16 Coarse Threac	65	80	
Ball Joint To Geared hut			
Lower	73	99	
Upper	65	88	
Idler Arm to Center Link	80	108	
Idler Arm to Frame - 7/16 Bolts	60	81	
Idler Arm to Frame - 12mm Bolts	90	122	
Intermediate Shaft to Steering Gea	60	81	
Pitman Arm to Center Link	80	108	
Pitman Arm to Steering Gea	185	250	
Steering Gear Mount Bolts	60	81	
Steering Wheel to Shaf	35	47	
Tie Rod End to Center Link or Hul	70	95	
Rear Tie Rod to Frame	260	354	

*Wheel (2-Piece Steel)

		Standard (ft-lb)	Metric (Nm)
Lug Nut, Tapered		110	149
Wheel Half Lock-nut			
	Initial	85	115
	Final	125	170

*Wheel (1-Piece Steel)

Standard (ft-lb) Metric (Nm)
Lug Nut, Flangec 140 190

*Wheel (1-Piece Aluminum)

Standard (ft-lb) Metric (Nm)
Lug Nut, Tapered 110 149

*Wheel (2-Piece Aluminum)

		Standard (ft-lb)	Metric (Nm)
Lug Nut, Tapered		110	149
Wheel Half Lock-nut			
	Initial	50	68
	Final	75	102

*NOTE: Torque bolts in proper sequence for each step (see owners manual)

Beadlock / Runflat (Cam Style)

<u> </u>	Standard (ft-lb)	Metric (Nm)
Beadlock Pinch Bol	60	68
Runflat Cam Bolt (before cam adjust	1-7	1.4-9.5
Runflat Cam Bolt (after cam adjust	45	68

Runflat (Cross Bolt Style)

	Standard (ft-lb)	Metric (Nm)
Runflat Cross Bolt	22	30
Locking Clip Screw	30-35	40-50

Suspension

	Standard (ft-lb)	Metric (Nm)
Control Arm Bushing	260	354
Control Arm Bracket	90	122
Shock Absorber Bottom Bracke	178	242
Shock Pin-Top/Bottom	300	408
Stabilizer Bar Link to Control Arn	70	95
Stabilizer to Bar Link	75	100

Key

Pipe Thread Sealan Thread Locker Blue Thread Locker Rec Anti-Seize (GM P/N 1052771) **Engine**

	Engin	e		
	6.5L / 6.5I	_ Turbo	6.2L I	NA
	Standard (ft-lb)	Metric (Nm)	Standard (ft-lb)	Metric (Nm)
Camshaft Thrust Plate			18	24
Cam Sprocket-Camshaft	125	171	55-66	75-90
Connectinig Rod Cap	45-52	61-71	45-52	61-71
Cylinder Head	See Service Bull	etin 98-02-03		
Initial	20	27	20	27
Final	55	75	50	68
Angle	90-100 deg (1/4 + turn)	90 deg (1/4 + t	urn in seq.)
Exhaust Manifold	26	35	18-25	24-34
Flexplate to Crank	65	88	65	88
Glow Plug	13	18	13	11-26
Injector Lines to Pump & Nozzle	24	33	20	27
Injector Nozzle	44-60	60-82	13-20	18-27
Injector Pump Gear-Pump Shaft	13-20	18-27	44-60	60-82
Intake Manifold	31	42	30	40
Lifter Retainer	15-20	20-27	15-20	20-27
Main Bearing Cap	(94-9	6)		
Late at t = 1. =	40	54	40	54
Initial/short				
Initial/snort Initial Long	40	54	40	54
Initial Long Final/Short Final/Long	40 100 110	136 149	40 100 110	54 136 149
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme	40 100 110 er Service Bulletin	136 149	100	136
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme	40 100 110 er Service Bulletin 89	136 149 98-02-02	100	136
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm	40 100 110 er Service Bulletin 89 17	136 149 98-02-02 10 23	100 110	136 149
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug	40 100 110 er Service Bulletin 89 17 20	136 149 98-02-02 10 23 27	100 110 48-120 156-240	136 149 5-14 18-27
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive	40 100 110 er Service Bulletin 89 17	136 149 98-02-02 10 23	100 110 48-120	136 149 5-14
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive	40 100 110 er Service Bulletin 89 17 20	136 149 98-02-02 10 23 27	100 110 48-120 156-240 25-37	136 149 5-14 18-27 34-50
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud	40 100 110 er Service Bulletin 89 17 20 25-37	136 149 98-02-02 10 23 27 34-50	100 110 48-120 156-240 25-37	136 149 5-14 18-27 34-50 80-101
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut	40 100 110 er Service Bulletin 89 17 20 25-37 66 35	136 149 98-02-02 10 23 27 34-50 90 48	100 110 48-120 156-240 25-37 59-74 35	136 149 5-14 18-27 34-50 80-101 48
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft	40 100 110 er Service Bulletin 89 17 20 25-37	136 149 98-02-02 10 23 27 34-50 90 48 56	100 110 48-120 156-240 25-37 59-74 35 41	136 149 5-14 18-27 34-50 80-101 48 56
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41	136 149 98-02-02 10 23 27 34-50 90 48 56 54	100 110 48-120 156-240 25-37 59-74 35 41	136 149 5-14 18-27 34-50 80-101 48 56 54
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41	136 149 98-02-02 10 23 27 34-50 90 48 56	100 110 48-120 156-240 25-37 59-74 35 41	136 149 5-14 18-27 34-50 80-101 48 56 54 45
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41	136 149 98-02-02 10 23 27 34-50 90 48 56 54	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45	100 110 48-120 156-240 25-37 59-74 35 41 40 33	136 149 5-14 18-27 34-50 80-101 48 56 54 45
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58 10	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts Turbo Exhaust Clamps	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts Turbo Exhaust Clamps Rocker Cover Bolt	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33 200 43 90	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58 10	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31 140-162	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42 190-220
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts Turbo Exhaust Clamps Rocker Cover Bolt Water Cross-Over to Cylinder Head	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33 200 43 90 13-25	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58 10 18-34	100 110 110 48-120 156-240 25-37 59-74 35 41 40 33 31 140-162	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42 190-220
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts Turbo Exhaust Clamps Rocker Cover Bolt Water Cross-Over to Cylinder Head	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33 200 43 90 13-25	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58 10 18-34	100 110 110 48-120 156-240 25-37 59-74 35 41 40 33 31 140-162	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42 190-220
Initial Long Final/Short Final/Long Main Bearing Cap 97-99 See Humme Oil Pan 6mm 8mm Oil Pan Drain Plug Oil Pump Drive Oil Pump Mounting Stud Nut Rocker Shaft Starter Timing Gear Cover Thermostat Housing Torsional Damper Turbocharger Mount Bolts Turbo Exhaust Clamps Rocker Cover Bolt Water Cross-Over to Cylinder Head Water Pump to Cover	40 100 110 er Service Bulletin 89 17 20 25-37 66 35 41 40 33 200 43 90 13-25 25-37	136 149 98-02-02 10 23 27 34-50 90 48 56 54 45 270 58 10 18-34 34-50	100 110 48-120 156-240 25-37 59-74 35 41 40 33 31 140-162	136 149 5-14 18-27 34-50 80-101 48 56 54 45 42 190-220

Alignment Specifications (All Models Unloaded)

Key

Pipe Thread Sealant Thread Locker Blue Thread Locker Red Anti-Seize (GM P/N 1052771)

Front			
Camber	1.05	\pm	0.25
Caster	1.80	±	1.00
Toe	0.00	±	0.03
Rear			
Camber	1.05	\pm	0.25
Caster			
Toe	0.00	+	0.03